



## TRIUMPH TRIDENT 900



### Packing list

- X2 link pipe pr 2301
- X2 (44-47mm) clamps pr 2063
- X2 carbon gasket pr 1883
- X2 silencers of choice
- X2 strap of choice

## Fitting instructions

- We strongly advise that this product is fitted by a qualified motorcycle mechanic.
- Please check packing list before you start.
- Secure motorcycle on level ground using paddock stand recommended.
- Smear a light coating of high temp silicone sealant to the inside of the slip joint.
- Insert carbon gasket into the link pipe then fit correct clamp and insert onto downpipe.
- Align stand stop.



- Nip up bolt not too tight for now just to support it.
- Fit silencer with clamp onto link pipe.
- Now fit strap onto silencer and to frame not to tight just to hold it there, image 3.



- Now repeat on other side.
- Align both sides until you are happy there the same.
- When happy starting from the front tighten all clamps and fasteners.
- Start engine and check for leaks.
- After first ride out check all fasteners for tightness, especially the baffle bolt.