



ZZR1200 LINK PIPES



Packing List:

2X LINK PIPES PR2273
2X CLAMPS 48/51mm PR2064
2X SILENCERS OF CHOICE AND STRAPS
2X CLAMPS 52mm/55mm PR2065
2X CARBON GASKETS 42.5/48.5/30mm PR1884

Fitting Instructions.

We strongly advise that this product is fitted by a qualified motorcycle mechanic.

Please check packing list before you start.

Always fit new gaskets

Secure motorcycle on level ground using paddock stand. Recommended!

Remove seats, panels and standard exhausts as necessary.

*Clean collector pipe of old gasket material, dirt and carbon deposits.
Insert new carbon gasket inside slotted end of link pipe.*

Fit 48/51mm Clamp on to pipe and insert it on to collector.



*Fit silencer with 52/55mm clamp on to link pipe.
Now fit strap onto silencer and to frame.
Repeat on the other side.*



*Rotate link pipes to obtain alignment and clearance.
Starting from the front working rearwards, tighten all clamps and fasteners.
Start engine and check for leaks.
Replace panels, seats etc.
After your first ride out, check all fasteners for tightness, especially the baffle bolts.*

