



SV650 2016 HI-LEVEL



PACKING LIST:

1X LINKPIPE

2X CLAMPS

1X SILENCER AND STRAP WITH RUBBER INSERT

1X MOUNTING BRACKET

2X SPACERS

3X M8 CAP SCREWS

4X M8 WASHERS

1X NYLOC NUT

1X TUBE OF SILICONE SEALANT

We advise that this product is fitted by an experienced motorcycle mechanic.

- **Please check packing list before you start.**
- **Secure motorcycle on level ground using a paddock stand. Recommended!**
- **Remove standard exhaust.**
 - **Fit the mounting bracket with spacers behind the footrest bracket.**



- **Fit clamp on the pipe and insert on to the collector.**



- **Fit the silencer with clamp on to the link pipe and fit the strap around the silencer and to the bracket.**



- **Starting from the front, working rearwards tighten all clamps and fasteners.**
- **Start the engine and check for leaks.**
- **After your first ride out, check all fasteners for tightness, especially the baffle bolt.**