



## CBR600FM-FW



- **PACKING LIST:**
- **1X DOWNPIPE AND COLLECTOR SET**
- **4X CYL PORT GASKETS**
- **1X LINKPIPE**
- **1X CARBON GASKET**
- **2X CLAMPS**
- **1X SILENCER AND STRAP WITH RUBBER INSERT**
- **1X TUBE OF SILICON SEALANT**

- **Fitting Instructions**
- We advise that this product is fitted by an experienced motorcycle mechanic.
- Please check packing list before you start.
- Secure motorcycle on level ground using a paddock stand. Recommended!
- Remove fairing panels.
- Remove standard silencer.
- Remove downpipes.
- Clean the cylinder ports of old gasket material, dirt and carbon deposits.
- Fit new port gaskets and one side of the downpipes with the collector.



- Fit the other downpipe side. DO NOT TIGHTEN YET.



- **Insert frame mounting bolt.**



- **Fit the clamp and insert the link pipe on to the collector.**



- **Fit the silencer with clamp on to the link pipe and fit the strap around the silencer and to the footrest bracket.**



- **Starting from the front, working rearwards tighten all clamps and fasteners.**
- **Start the engine and check for leaks.**
- **After your first ride out, check all fasteners for tightness, especially the baffle bolt.**