



TRIUMPH SPEED TRIPLE 1050 2011-16



- **PACKING LIST:**
- **2X LINK PIPES**
- **4X CLAMPS**
- **2X SILENCERS AND STRAPS WITH RUBBER INSERTS**
- **2X MOUNTING BRACKETS**
- **2X CAP SCREWS**
- **2X M8 NYLOC NUTS**
- **6X M8 WASHERS**
- **1X TUBE OF SILICON SEALANT**

- **Fitting Instructions**

- We advise that this product is fitted by an experienced motorcycle mechanic.
- Please check packing list before you start.
- Secure motorcycle on level ground using a paddock stand. Recommended!
- Remove seat and seat cowl.
- Remove standard silencers.
- Fit the brackets to the frame mounts and refit seat cowl .



- **Insert the link pipes into the collectors.**
- **Fit the silencers with clamps on to the link pipes and fit the straps around the silencer and to the brackets.**



- **Starting from the front, working rearwards tighten all clamps and fasteners.**
- **Start the engine and check for leaks.**
- **After your first ride out, check all fasteners for tightness, especially the baffle bolts.**