



THUNDERCAT DOWN PIPES



Packing List:

**1X DOWN PIPE SET PR1139
4X COPPER GASKETS PR1416
1X SILENCER GASKET PR1882
1X CLAMP PR2065
8X STUD NUTS AND WASHERS**

Fitting Instructions

We strongly advise that this product is fitted by a qualified motorcycle mechanic.

Please check packing list before you start.

Always fit new gaskets!

Secure motorcycle on level ground using paddock stand. Recommended!

Remove seats, panels and standard exhausts as necessary.

Remove old gaskets and clean the ports of dirt, corrosion and carbon deposits.

Fit new gaskets into exhaust ports, using a small amount of silicone to hold in place.

Now fit assembly to motorcycle. Fit exhaust collars and stud nuts finger tight.

NOTE Replacement Delkevic stud nuts have an internal recess.

Which have to be facing, towards the cylinder head.

Attach rear mounting bolt loosely.

Starting from the front working rearwards tighten all nuts and bolts.

After refitting silencer, start engine and check for leaks.

Replace panels, seats etc.

After your first ride out, check all fasteners for tightness.