

GTR1400 LINK PIPE



Packing List:

1X LINK PIPE PR2132

1X CLAMP 56/59MM PR2066

1XSILENCER OF CHOICE AND STRAP

1X CLAMP 52/55MM PR2065

1X DROPDOWN BRACKET PR1433

1X M8x20MM CAP SCREW

1X M8 NYLOC NUT

2X M8 WASHERS

1X STAND STOP RUBBER PR2235

Fitting Instructions

We strongly advise that this product is fitted by a qualified motorcycle mechanic. Please check packing list before you start.

Secure motorcycle on level ground using paddock stand. Recommended! Remove standard silencer.

Clean collector pipe of old gasket, dirt and carbon deposits.

Fit correct Clamp to link pipe and insert it on to collector.



Fit dropdown bracket to the inside of footrest hanger. Fit silencer with clamp on to link pipe. Now fit strap onto silencer and to bracket.



Rotate link pipe to obtain alignment and clearance.

Starting from the front, tighten all clamps and fasteners.

Start engine and check for leaks.

After your first ride out, check all fasteners for tightness, especially the baffle bolt.