



TRIUMPH STREET TRIPLE 675



- **PACKING LIST:**
- **2X LINK PIPES**
- **4X CLAMPS**
- **2X SILENCERS AND STRAPS WITH RUBBER INSERTS**
- **2X MOUNTING BRACKETS**
- **2X M8x 20MM CAP SCREWS**
- **2X M8 NYLOC NUTS**
- **4X M8 WASHERS**
- **1X TUBE OF SILICON SEALANT**

- **Fitting Instructions**

- We advise that this product is fitted by an experienced motorcycle mechanic.
- Please check packing list before you start.
- Secure motorcycle on level ground using a paddock stand. Recommended!
- Remove standard silencers.
- Clean the collector pipes of old gasket material, dirt and carbon deposits.
- Fit the clamp and insert the pipe on to the collector.
- Fit the mounting brackets to the frame.



- **Fit the silencer with clamp on to the link pipe and fit the strap around the silencer and to the bracket.**



- **Starting from the front, working rearwards tighten all clamps and fasteners.**
- **Start the engine and check for leaks.**
- **After your first ride out, check all fasteners for tightness, especially the baffle bolts.**