



TRIUMPH STREET TRIPLE 675



- **PACKING LIST:**
- **1X LINK PIPE**
- **2X CLAMPS**
- **1X SILENCER AND STRAP WITH RUBBER INSERT**
- **1X MOUNTING BRACKET**
- **2X SPACERS**
- **1X M8x 20MM CAP SCREW**
- **1X M8 NYLOC NUT**
- **2X M8 WASHERS**
- **1X TUBE OF SILICON SEALANT**

- **Fitting Instructions**

- We advise that this product is fitted by an experienced motorcycle mechanic.
- Please check packing list before you start.
- Secure motorcycle on level ground using a paddock stand. Recommended!
- Remove standard silencer.
- Clean the collector pipe of old gasket material, dirt and carbon deposits.
- Fit the clamp and insert the pipe on to the collector.



- Remove rubber bushes from footrest bracket and replace with stepped spacers.



- Fit the mounting bracket.



- Fit the silencer with clamp on to the link pipe and fit the strap around the silencer and to the bracket.



- Starting from the front, working rearwards tighten all clamps and fasteners.
- Start the engine and check for leaks.
- After your first ride out, check all fasteners for tightness, especially the baffle bolt.