



**Packing List:**

- 1X LINK PIPE PR2259
- 1X SILENCER OF CHOICE AND STRAP
- 1X 48/51 CLAMP
- 1X 52/55 CLAMP

**Fitting Instructions**

*We strongly advise that this product is fitted by a qualified motorcycle mechanic.*

*Please check packing list before you start.*

*Secure motorcycle on level ground using paddock stand.*

*Remove the small inspection cover from underneath the seat unit and detach valve cable.*



*Remove lambda sensor, standard silencer and valve cable.*

*Clean collector pipe of old gasket material, dirt and carbon deposits.*

*Fit the 48/51 clamp to the link pipe and insert it on to collector.*

*Fit the silencer with 52/55 clamp on to link pipe.*



*Now fit the strap onto the silencer and to the outside of the footrest hanger.*

*Rotate the link pipe to obtain alignment and clearance.*

*Refit lambda sensor.*

*Starting from the front, tighten all clamps and fasteners.*

*Start the engine and check for leaks.*

*After your first ride out, check all fasteners for tightness.*