



YAMAHA BOLT



- **PACKING LIST:**
- **1X LINK PIPE**
- **2X CLAMPS**
- **1X SILENCER**
- **1X MOUNTING BRACKET**
- **1X HEAT SHIELD ADAPTOR**
- **2X SPACERS**
- **MOUNTING HARDWARE**
- **1X TUBE OF SILICON SEALANT**

- **Fitting Instructions**

- We advise that this product is fitted by an experienced motorcycle mechanic.
- Please check packing list before you start.
- Secure motorcycle on level ground using a paddock stand. Recommended!
- Remove standard silencer and the large cast bracket.



- Clean the collector pipe of old gasket material, dirt and carbon deposits.
- Fit the clamp and insert the link pipe on to the collector.
- Fit the Delkevic bracket to the silencer.
- Fit the silencer with clamp on to the link pipe and attach to the frame with the spacers.



- Starting from the front, working rearwards tighten all clamps and fasteners.
- Fit the heat shield on to the link pipe.
- Start the engine and check for leaks.
- After your first ride out, check all fasteners for tightness, especially the baffle bolt.