

YAMAHA V-MAX 1200 ENGINEPROTECTOR BARS



- Fitting Instructions
- We advise that this product is fitted by an experienced motorcycle mechanic.

- Secure motorcycle on level ground using a paddock stand. Recommended!
- Remove these bolts.



• Fit the L/Hand engine bar using the supplied Delkevic hardware.



• Repeat on the R/hand side using the frame spacer.



- Starting from the front, working rearwards tighten all fasteners.
- After your first ride out, check all fasteners for tightness.