



CBR250R MC41 LINK PIPE

Packing List:

1X LINK PIPE PR2252
1X CARBON GASKET 38.5x44.5mm PR1883
1X CLAMP 44x47mm PR2063
1X SILENCER OF CHOICE AND STRAP
1X CLAMP 52x55mm PR2065

Fitting Instructions

We strongly advise that this product is fitted by a qualified motorcycle mechanic.

Please check packing list before you start.

Secure motorcycle on level ground using paddock stand. Recommended!

Remove standard exhaust.

Clean collector pipe of old gasket material, dirt and carbon deposits.

Insert new carbon gasket inside slotted end of link pipe.

Fit clamp to link pipe and insert it on to collector.

Fit silencer with clamp on to link pipe.

Now fit strap onto silencer and to frame.

Rotate link pipe to obtain alignment and clearance.

Starting from the front, tighten all clamps and fasteners.

Start engine and check for leaks.

After your first ride out, check all fasteners for tightness.