

XJR 1200/1300 SILENCER KIT



- PACKING LIST
- 2X LINK PIPES
- 4X CLAMPS
- 2X CARBON GASKETS
- 2X SILENCERS OF CHOICE AND STRAPS
- 2X FOOTREST EXTENDER PLATES (FOR 1995-03 MODELS)
- 8X M8x30mm CAP SCREWS
- 4X M8 NYLOC NUTS
- 12X M8 WASHERS

- Fitting Instructions.
- We strongly advise that this product is fitted by an experienced motorcycle mechanic.
- Please check packing list before you start.
- Always fit new gaskets
- Secure motorcycle on level ground using paddock stand. Recommended!
- *Remove standard exhausts and footrest brackets.*
- Clean collector pipe of old gasket material, dirt and carbon deposits.
- Fit the extension plates to the frame.



• *Refit footrest hangers using cap screws, nuts and washers.*



- Insert new carbon gasket inside the slotted end of link pipe.
- Fit correct Clamp and insert it on to collector, aligning the stand stop.



- Fit the silencer with clamp on to the link pipe.
- Now fit the strap around the silencer and to the footrest bracket.



- Repeat on the other side.
- Rotate link pipes until you happy with alignment and clearance.
- Starting from the front, tighten all clamps and fasteners.
- Start the engine and check for leaks.
- After your first ride out, check all fasteners for tightness, especially the baffle bolts.