

ZX6R 2009-16 LINK PIPE



Packing List:

1X LINK PIPE PR1946 1XSILENCER OF CHOICE AND STRAP 1X CLAMP 52-55mm PR2065

Fitting Instructions.

We strongly advise that this product is fitted by a qualified motorcycle mechanic.

Please check packing list before you start.

Secure motorcycle on level ground using paddock stand. Recommended! Remove plastic fuel tank covers and seat.

Loosen exhaust servo cable wheel using a T25 anti tamper torx bit. WARNING! Hold hexagon with large wrench to avoid damage to servo.



Remove cables and silencer as an assembly. Keep standard collector clamp.

Fit link pipe, longest end first.



Nip up bolt, not too tight for now, just to support it.

Fit silencer with clamp on to link pipe. Now fit strap onto silencer and to frame.



KIT040K

Rotate link pipe to obtain alignment and clearance, Starting from the front, tighten all clamps and fasteners.

Start engine and check for leaks. Replace panels, seats etc.

After your first ride out, check all fasteners for tightness, especially the baffle bolt.