

KAWASAKI Z300



- PACKING LIST:
- 1X LINK PIPE
- 2X CLAMPS
- 1X SILENCER AND STRAP WITH RUBBER INSERT
- 1X MOUNTING BRACKET
- 1X SPACER
- 1X M8x 40MM CAP SCREW
- 1X M8 NYLOC NUT
- 2X M8 WASHERS
- 1X TUBE OF SILICON SEALANT
- Fitting Instructions

- We advise that this product is fitted by an experienced motorcycle mechanic.
- Please check packing list before you start.
- Secure motorcycle on level ground using a paddock stand.
 Recommended!
- Remove standard silencer.
- Clean the collector pipe of old gasket material, dirt and carbon deposits.
- Fit the new carbon gasket on to the OEM collector outlet.
- Fit the clamp and insert the link pipe on to the collector.
- Fit the silencer with clamp on to the link pipe and fit the strap around the silencer and to the spacer and bracket.



- Starting from the front, working rearwards tighten all clamps and fasteners.
- Start the engine and check for leaks.
- After your first ride out, check all fasteners for tightness,

especially the baffle bolts.